



MANUAL 1976

6 HP

**MODEL 6604
6605**

INTRODUCTION	1
GENERAL SERVICE INFORMATION	2
FUEL SYSTEM	3
IGNITION SYSTEM	4
POWER HEAD	5
LOWER UNIT	6
MANUAL STARTER	7